

CR-78 SERVICE NOTES

Panel no.235
(072-235)

Switch
SRM101C
(001-242)
Knob no.44
(016-044)

LED SLP-131B
(red)
(019-013)

Switch
SRA202B
(001-244)

Switch
SRM1025
(001-243)

Switch
SLR-823
(001-246)

Knob No.67
(016-067)

Switch
SLR-322
(001-231)

Switch
KCA10037
(001-273)

Pots.
LYE6B001-10KB
(029-410)

Knob No.48
(016-048)

Pot.
LYE6B001-50KB
(029-411)

Switsh
SUF53
(001-241)
Knob No.80
(016-080)

Pot.
EVHCOAP25B14
(026-021)

Pot.
EVHCOAP25B15
(026-024)

Knob No.43
(016-043)

Switch
SDG5P
(001-215) 100V
(001-216) 117V
(001-217) 220/240V
Knob No.81
(016-081)

LED SLP-131B red
(019-013)

Switch
SLR-323
(001-245)

Switch
KCA10037
(001-273)

Switch
SLR-322
(001-231)

Switch
SUFA2
(001-239)

Cabinet No. 113
(081-113)

Base (foot) No.20
(111-020)

Switch
SUFB2 (001-240) Buttons


(016-008) Gray
(016-085) White
(016-086) Red
(016-087) Green
(016-088) Yellow
(016-089) Blue

Switch HSW0372-01-030
(001-206)


Jacks SG7622 #8 (009-012)

LOGIC SYMBOL

F4013



CONNECTION DIAGRAM DIP (TOP VIEW)



NOTE:
The Flatpak version has the same pinouts (Connection Diagram) as the Dual In-line Package.

F4013 TRUTH TABLES

SYNCHRONOUS INPUTS		OUTPUTS	
CP	D	Q_{n+1}	\bar{Q}_{n+1}
┐	L	L	H
┐	H	H	L


Conditions: $S_D = C_D = \text{LOW}$

ASYNCHRONOUS INPUTS		OUTPUTS	
S_D	C_D	Q	\bar{Q}
L	H	L	H
H	L	H	L
H	H	L	L

L = LOW Level
H = HIGH Level
┐ = Positive-Going Transition
X = Don't Care
 Q_{n+1} = State After Clock Positive Transition


F4001 QUAD 2-INPUT NOR GATE

LOGIC AND CONNECTION DIAGRAM DIP (TOP VIEW)




SN74LS174,

SN54174, SN54LS174, SN54S174 ... J OR W PACKAGE
SN74174, SN74LS174, SN74S174 ... J OR N PACKAGE
(TOP VIEW)



SN74LS175, F40175

SN54175, SN54LS175, SN54S175 ... J OR W PACKAGE
SN74175, SN74LS175, SN74S175 ... J OR N PACKAGE
(TOP VIEW)



NOTE:
In using F40175,
refer to note
on page 8.

QUADRUPLE D-TYPE FLIP-FLOPS


FUNCTION TABLE (EACH FLIP-FLOP)

INPUTS		OUTPUTS	
CLEAR	CLOCK	Q	\bar{Q}
L	X	X	X
H	┐	H	L
H	┐	L	H
H	L	Q_0	\bar{Q}_0


H = high level (steady state)
L = low level (steady state)
X = irrelevant
┐ = transition from low to high level
 Q_0 = the level of Q before the indicated steady-state input conditions were established.
┐ = '175, 'LS175, and 'S175 only

DECODERS/DEMULTIPLEXERS

SN54LS138, SN54S138 ... J OR W PACKAGE
SN74LS138, SN74S138 ... J OR N PACKAGE
(TOP VIEW)



'LS138, 'S138




'LS138, 'S138 FUNCTION TABLE

INPUTS		OUTPUTS							
ENABLE	SELECT	G1	G2*	C	B	A	Y0	Y1	Y2
X	H	X	X	X	X	X	H	H	H
L	X	X	X	X	X	X	H	H	H
H	L	L	L	L	L	L	H	H	H
H	L	L	L	L	L	H	H	H	H
H	L	L	L	L	H	L	H	H	H
H	L	L	L	H	L	L	H	H	H
H	L	L	H	L	L	L	H	H	H
H	L	H	L	L	L	L	H	H	H
H	L	H	L	L	H	L	H	H	H
H	L	H	L	H	L	L	H	H	H
H	L	H	L	H	H	L	H	H	H
H	L	H	H	L	L	L	H	H	H
H	L	H	H	L	H	L	H	H	H
H	L	H	H	H	L	L	H	H	H
H	L	H	H	H	H	L	H	H	H
H	L	H	H	H	H	H	L	H	H
H	L	H	H	H	H	H	H	L	H
H	L	H	H	H	H	H	H	H	L
H	L	H	H	H	H	H	H	H	H


*G2 = G2A + G2B
H = high level, L = low level, X = irrelevant

HEX INVERTERS




SN5404 (J) SN7404 (J, N)
SN54H04 (J) SN74H04 (J, N)
SN54L04 (J) SN74L04 (J, N)
SN54LS04 (J, W) SN74LS04 (J, N)
SN54S04 (J, W) SN74S04 (J, N)

QUADRUPLE 2-INPUT POSITIVE-NAND GATES



SN5400 (J) SN7400 (J, N)
SN54H00 (J) SN74H00 (J, N)
SN54L00 (J) SN74L00 (J, N)
SN54LS00 (J, W) SN74LS00 (J, N)
SN54S00 (J, W) SN74S00 (J, N)

CR-78 BLOCK DIAGRAM



SPECIFICATIONS

OUTPUT IMPEDANCE

H: 220k ohms L: 10k ohms

OUTPUT LEVEL

H: 3.5Vpp into 220k

L: 5.5Vpp into 10k
(VOL. ACC. max)

TRIGGER: +15V

EXT. CLOCK

+5V--- +15V
min. 5ms in length

POWER CONSUMPTION

9W (117V)

13W (220/240V)



DIMENSIONS

300(W)x280(D)x250(H) mm

11.8 x 11.0 x 8.1 in

NET WEIGHT

5.5Kg 12.1 lbs



EXT. CLOCK CIRCUIT:
independent of OP-104
S/N up to 780699, mounted
on OP-129.


FUSES RATING

F1 (-5V)	F2 (+15V)	F3 (+5V)	F4 (prim.)
SGA 0.125A (008-022)	SGA 1A (008-026)	SGA 0.5A (008-024)	SGA 0.5A (008-024)
CEE T50mA (008-053)	CEE T250mA (008-060)	CEE T400mA (008-062)	CEE T250mA (008-060)

CR-78 CIRCUITS TIMING DIAGRAM



 μ PD8048

(Top View)

One chip microcomputer μ PD8048C-015


WRITE Switch

Flow Chart



The μ PD8048 is an 8-bit parallel computer fabricated on a single silicon chip. The 8048 contains a 1k x 8 ROM program memory, a 64 x 8 RAM memory, 27 I/O lines, an 8-bit timer/counter and clock circuits. Used in the CR-78 is a μ PD8048C-015 version in which the programs and data dedicated to the CR-78 are stored in program memory.

CR-78 Flow Chart



CIRCUIT DESCRIPTION

The CR-78 is a computerized rhythm machine whose rhythms are controlled by the resident computer through internally stored programs. Rhythms other than stored can be programed as desired by using the built-in expansion ROM and RAMs. Sequential program order is outlined in the flow chart and the timing diagram shows relationship among principal circuits waveforms. (see previous page) The following description is composed of two sections: General Introduction and Detailed Function. Title numbers refer to those in flow chart.

GENERAL INTRODUCTION

1. POWER ON

When power is first applied, two oscillators start oscillation: MASTER OSCILLATOR, determines rhythm tempo, ranging from 5Hz to 100Hz; CLOCK GENERATOR, generates timing pulses for the 8048 in each step cycle.

2. 2B. SWITCH SANNING

Even in the stop mede, the computer needs to store a data on switching status so as to output rhythm patterns immediately after the START/STOP switch is depressed. And also a status data is needed at the beginning of a measure. The switch reading to obtain a switch set-up data is refereed to as switch scanning. From Port 2 of 8048, signals are routed through the Decoders IC107 and IC108, and the switch matrix to Port 1. Combination of two port's pins according to switch settings becomes a data on switch status. After a rhythm runs, scanning is done onee for each measure.

3. PROCESSING and PREPARING DATA

The 8048 prepares the next data according to the internal program based on switch scanning data.

4. SCANNING CANCEL VOISE SWITCH

Since switch scanning is performed once for one measure during rhythm running, switching during the measure is effective in the subsequent measure. However, "CANCEL VOICE" is scanned every cycle to cancel the unwanted voice at once whenever it is specified.

5. SENSING START/STOP SWITCHING

As long as T1, the START/STOP sensing input terminal of μ PD8048 is kept low, the program routine is not allowed to break loop through 1-5, returning to 1. When the START/STOP switch is pushed while a rythm stops, T1 is pulled to high to start a rhythm and falls to low when the START/STOP is pushed again(stop)

6. SENSING MASTER OUTPUT FALLING

Although each circuit operates its given task in sequence under the control of timing pulses from the CLOCK GENERATOR, each program step must keep pace with oscillation of the master osc. (rhythm tempo) by sensing the falls and rises of waveforms of the master oscillator. A program step proceeds to the next step when the master's trailing edge goes to negative.

7. SENSING WRITE SWITCHING

When the WRITE switch is tapped, the write hold circuit IC118 is set, applying high level to INT, and causing program routine to jump to 7B.

7B. WRITING PROGRAM RHYTHM

Scanning signals from $\bar{6}$ and $\bar{7}$ of the decoder IC108 tell the computer which position of INSTRUMENT and which PROGRAM push switch is selected. Then the data on PROGRAM rhythm are stored into the RAMs IC102 and IC103 under the control of a program from the ROM IC104. The RAMs provide memory size for two measures for each voice.

8. SENSING MASTER RISING

The computer executes a program, synchronizing its step with a rhythm tempo. As soon as TO receives the rise of a master square, 8048 starts to produce rhythm patterns by sending data and control signals out from Port 1 and 2.


9. OUTPUTTING DATA

The Port 1 this time serves as an output port, feeding data for rhythm patterns (VOICES) and LEDs (TRACK) to the latehes IC112-IC116 which selectively latch them in sequence under the control of signals coming from the Port 2 through the Decoder IC107. The computer performs the entire loop once for one cycle of master oscillator and 48 times per measure.

FUNCTION -Detail-

1. POWER ON


Resetting of the START/STOP fli-flop IC109A inhibits a rhythm from running by holding T1 of μ PD8048 at low level until the START/STOP switch is first tapped. When power is on, since the both pins 12 and 13 of IC111A are grounded momentarily, its output (pin 11) level swings to high re-setting the RS flip flop IC109A which in turn develops high output at pin 2, setting T1 level to low (through Q5-Q7, IC117A and Q11). Pins 12 and 13 of IC111 will go positive as C103 charges, but IC109A output is kept high until the START/STOP switch is depressed.



2. NO DETAIL

2B. SWITCH SCANNING

Switch scanning cycle initiates to generate internally programed binary signals from the Port 2, P24-P27, feeding them to IC108, binary-to-hexadecimal decoder, from which decoded signals are routed to respective switch groups. From the decoder only one pin outputs negative going pulse while the rest pins output H, and the next pin outputs H with the rest L. These outputs of signals occur in sequence within a time interval of microseconds and repeats over and over again every few milliseconds until the START/STOP switch is depressed to run the rhythm. After running, scanning siganls are outputed once at the onset of a measure. This means that changing of any switch setting during a measure is ignored by the computer unless switch setting is kept unchanged until the next scanning. Similarly, changing the MEASURE of VARIATION in AUTO mode will be made into effective only after previously specified measure(s) has passed.





In MANUAL mode, VARIATION change during a measure is enabled at the beginning of the next measure by holding that changing information until the next scanning is performed.

For this purpose the MANUAL VARI hold circuit is used which consists of IC119. When the START/STOP switch is pressed while a rhythm stops, the RS flip flop IC119 (pins 1-6) is reset by a pulse from $\bar{0}$ of IC108, switching pin 3 to H and pin 6 to L.

Depressing the MANUAL switch during rhythm running sets the FF IC119A/B, holding pin 6 or pin 13 at H. When a master output goes low, a scanning pulse is generated from 4 of IC108, after inverted by IC121, it is NANDed with pin 13 input, causing pin 11 to develop a negative going pulse which is detected by the 8048 through P16, this is MANUAL "ON" information.

After scanning, a reset pulse is applied from 0 of IC108 to pin 2 through the NAND circuit IC119D.



3. NO DETAIL

4. NO DETAIL

5. SENSING START/STOP SWITCHING

The START/STOP FF IC109A receives a positive going pulse each time the START/STOP switch is pushed, switching its output H or L and holding it until the next push is made. Pushing the START/STOP switch applies a positive pulse to pin 3 of the START/STOP FF IC109A causing it to have a high or low output until the START/STOP switch is pressed again. The output from the FF is applied through Q5, Q6 and OP-100 to pin 6 of the comparator IC117A which provides a reference voltage at pin 5. When an input to pin 6 of the comparator exceeds the reference voltage of pin 5, the comparator senses it, sending output to:

1. T1 of 8048 to start the rhythm,
2. the master oscillator and 8 and 16 beat dividers IC109B and IC110 through the one shot pulse generator IC111 (pins 1-6) to reset them and to synchronize their starts.

When the voltage at pin 6 of the comparator drops below the reference voltage, low output is applied to T1 to stop the rhythm.

However, if the FADE IN or FADE OUT switch is in closed position, voltage swing at T1 is delayed behind START/STOP switching due to the time constant in the fade circuit.(detailed later)

6. MASTER OSCILLATOR

The master oscillator output waveform has a duty ratio of over 50%. When the WRITE switch is tapped, the WRITE FF IC118 is set, applying high output to INT pin of 8048 which will go low when the master output falls. This is a "WRITE ON" information to the computer, upon receiving the "write on" information, switch scanning pulses are sent from 0, 7, 9 and 10 of the decoders and associated data are memorized into external RAMs IC102 and IC103. The circuit configuration and function of the WRITE FF are much the same as in the MANUAL FF except for reset timing. As shown in the figure, whenever the write switch is tapped, as long as it is occurred during master's high level period, information is recognized by the computer when the master output

falls, however, if the write switch is tapped during low level period, it is treated as it is occurred during the next high level period, and then, sound is reproduced, being delayed by 1/2 cycle of the master oscillator. The longer high level period of the master oscillator waveform is intended to compensate for delayed timing of key operation.


7. NO DETAIL

7B. WRITING PROGRAM RHYTHM

As described in section 6, when the write switch is tapped during a measure, information on PROGRAM rhythm are stored in RAMs at the subsequent master square trailing edge, and INT of 8048 receives H input from the write hold circuit which consists of IC118 which functions in the same way as in the MANUAL VARI.(in this case reset pulse is fed from pin 14 or 9 of IC107). When the write switch is depressed during a measure, H level is applied at INT pin and is held until master falls, this is "write on" information, and the computer detects through switch scanning (pulses from 6 and 7 of IC108) which of PROGRAM switches and which position of INSTRUMENT switch is selected. The selected INSTRUMENT is first stored into RAM, then rhythm patterns are stored. When the same instrument has been addressed in the RAM track, rhythm patterns being written are added to the patterns previously stored in the RAM and will not be stored in another track independently.


Required bit numbers for two measures are:
4 (PROGRAM) x 4 (INSTRUMENT) x 96 steps (48 x 2) = 1536 bits.
Data transfer to/from RAMs and ROM are performed as follows:
ALE (Address Latch Enable)
This signal occurs once for 15 Clock Generator frequency, that is, 250kHz, and latches address being outputted from DB, through internal program, delivering the latched signals to RAMs and ROM.

ROM (IC104)
Program memory addressed by the address signals from the latches IC105, IC106 and P20 and P21 is fetched when PSEN is low at 2B and 7B of the flow chart.




RAM (IC102, IC103)
Stored data are read when RD is low at 2B and 7B of the flow chart. Information are stored when WR is low at 7B of the flow chart.

CYCLE TIMING FOR EXTERNAL DATA MEMORY (RAM) WRITE/READ



CYCLE TIMING FOR EXTERNAL PROGRAM MEMORY (ROM) READ





8. 9. DATA OUTPUT
- LATCH CIRCUITS -

When the program proceeds at data output routine, Port 1 this time acts as an out-put port since it is a bidirectional port, representing the data through internal program memory or external ROM and RAMs, data are sent from P10-P17 to IC112-IC116 latch circuits whose clock input pins receive latch signals from port 2 via decoder IC107. When a latch pulse goes positive while a data signal is fed onto the clock pin, the data is latched and sent to the VOICING circuit or LED. When the latched data is for voicing, it is applied after inverted and amplified by a buffer.

There are three kinds of latched outputs, as the master output goes negative, Qs and Qs of IC112-IC114 are cleared, maintaining their pulse lengths almost the same as the master wave length.

On the other hand, Qs of IC115 and IC116 are held L until the next latch signal comes since these clear pins of IC115 and IC116 are not connected to the master oscillator output.

Note: since the time interval between pulses within the arrows marked by * is 70µs, they are considered to occur at the same time.



= FADE and ACCENT =

As described in section 4, the FADE circuits on OP-100 are enabled when the FADE IN and/or FADE OUT switches are turned on to make the rhythm sounds gradually louder (VCA) as a rhythm starts and to stop the rhythm (T1) as sounds die away.



These timings are determined by the RC constants in the FADE circuits.

Accent pulses are also affected by the FADE circuits in amplitude ratio and are mixed with the sound control voltage in the summing amp. IC117 from which incorporate control voltages are sent to the VCA on the VG-11 to control rhythm volume.

= SOUND KILLER =


These circuits "kill" undesired sounds resulted from transient voltages on their way to output:

1. When power is on, Q512 on the VG-11 is not supplied enough collector voltage to amplify a input signal until C558 charges to some extent.
2. When power is off, C558 discharges through Q535 and Q532 on the VG-11, grounding pin 1 of VCA IC502.
3. The circuit comosed of Q12 and Q13 on the GL-9 is identical and functions in the same manner as the circuits described above, but is used to protect the RAMs and to prevent disorderly running of 8048.



NPC4558

TOP VIEW




BA662



AM2708P



BLOCK DIAGRAM





PIN CONNECTION DURING READ OR PROGRAM

MODE	PIN NUMBER							
	DATA I/O 9, 11, 13, 17	ADDRESS INPUTS 1 B, 22, 23	V _{SS} 12	PROGRAM 1B	V _{DD} 19	CS/WE 20	V _{BB} 21	V _{CC} 24
HEAD	DOU1	A _{IN}	GND	GND	+12	V _{IL}	-5	+5
DESELECT	HIGH IMPEDANCE	DON'T CARE	GND	GND	+12	V _{IH}	-5	+5
PROGRAM	D _{IN}	A _{IN}	GND	PULSED 26V	+12	V _{IHW}	-5	+5


µPD5101C-E




GL-9A (142-009A)
(Etch mask 052-438A)
Serial No. 780700-821050
Use GL-9B for replacement



OP-100A (149-100A)
(Etch mask 052-449A)



view from foil side




OP-100

Serial no. up to 780699

Use OP-100A for replacement


RS-15A (148-015A)
(Etch mask 052-052-444A)



view from foil side

RS-15


Serial no. up to 780699
Use RS-15A for replacement



SRM101C
(001-242)



SRM1025
(001-243)


RS-14 (148-014)
(Etch mask 052-445)
view from foil side



RS-17 (148-017)
(Etch mask 052-446)
view from foil side


IC101	MPD8048-015	IC109.110	MC14013 B	IC120-122	74LS04
IC112.103	MPD5101C-E	IC111	MCM4001 B	IC112.113 115.116	74LS175 OR MC144175 B
IC104	Am 2708DC-023	IC114	74LS174	Q12	2SA1015 Y
IC105.106	74LS175	IC117	MPC4558 C	Q(except Q12)	2SC1815 G R
IC107.108	74LS138	IC118.119	74LS00	D	1S158 B
				LD	SLP131 B





The GL-9 and GL-9A circuits (S/N up to 821050) are the same as the GL-9B circuit shown above except for the portions indicated by the double dotted lines, (1, 2, 3, 4,). The GL-9 and GL-9A circuits for these portions are shown on page 8.

**LOGIC & RHY' SWs
CIRCUIT DIAGRAM**



Jack #12

SG7622

R252
D150
B50
R250
E
C
I

TO (26) OF GL-9 (GND)


TO (77) OF GL-9

FROM (76) OF GL-9

OP-129 (149-129)
Serial No. up to
EXT. CLOCK circuit
OP-129 independent


Collect In Write & Vari

R251
100K





OP-129 (149-129)
Serial No. up to 780699

EXT. CLOCK circuit is arranged on
OP-129 independently of OP-104.



In the dotted lines shown are circuit configuration and components of VG-11 (S/N up to 780699), remainings are almost the same as those on VG-11A which can replace the VG-11.

OP-103A (149-103A)
(Etch mask 052-447A)
view from foil side




VG-11A (143-011A) (Etch mask 052-437A)
Serial No. 780700 and higher


Q501-513	2SC900-F	IC501	MC14069
Q514-532	2SC1815-GR	IC502	BA662
Q533	2SC828-R(NZ)	IC503	μ A78M05
Q534-535	2SA1015-Y	IC504	μ A78M15
D500-526	1S1588	IC505	μ A78L05

Components on foil side:

VG-11 - R645, C592
VG-11A- D533



RHYTHM PATTERNS




WALTZ



SHUFFLE



SLOW ROCK



SWING



FOX TROT




TANGO



BOOGIE



ENKA



BOSSA NOVA



SAMBA



MAMBO



CHA CHA



BEGUINE




RHUMBA



ROCK-1



ROCK-2



ROCK-3



ROCK-4




DISCO-1



DISCO-2




FILL IN



ADJUSTMENT & CHECKING

1. MASTER OSCILLATOR FREQUENCY (RHYTHM TEMPO)
- Connect an oscilloscope to Q1 collector or pin 76 on GL-9.
- 1-1. Set TEMPO knob to full clockwise position (10).
Adjust VR101 for T = 10ms.
- 1-2. Turn the TEMPO control fully counterclockwise.
Adjust VR102 for T = 10ms.
Bottom half must be perfectly square.




2. FADE TIME
- To be adjusted after step 1 is finished.
- With rhythm (may be SAMBA-B) running, turn TEMPO fully clockwise.
- Set FADE OUT to SHORT.
- Depress START/STOP button.
- 2-1. When sound becomes inaudible, count the number of LED flashes until the LED stays on steadily.
Factory set ranges 4 (1.5sec) to 55 (2.4sec).
- 2-2. To adjust, turn VR103 on GL-9.

3. RHYTHM VOICE
- Figures in the table at the right show factory standard and may be slightly deviated for personal taste or to meet frequency response of an amplifier being used.

Set all rhythm buttons to "off".
Depress START/STOP button to start the rhythm.

VOICE to be adjusted	Oscilloscope		Frequency			Remark (-) non- adjustable: just check	Decay time		Amplitude		
	H IN	V IN	Adjust	for			Adjust	for	Adjust	for	
				ms	Hz			ms		Vpp	
To gate each VOICE circuit, BD through LC: connect TS-1 to WRITE jack and tap it as necessary with INSTRUMENT SELECTOR set to the voice to be adjusted.											
BD	connect to Q15 collector with TRIG. set at EXT.	connect to pin 34 on VG-11	VR57	16	62.5	w BALANCE set to the lowest	VR58	100	—	0.4	
SD			—	3.0	340(Drum)	—	60	VR61	0.4		
RS			—	6.67	1480	—	5	—	0.8		
HH			Move BALANCE knob to the highest.			Adjusting VR60 on any one VOICE makes all.	—	60	VR60	0.4	
CY							—	350		0.4	
M							—	20		0.4	
C				0.43	2630	—	18	—	0.15		
HB			VR51	1.66	600	VR52	40	—	0.15		
LB			VR53	2.5	400	VR54	40	—	0.15		
LC			VR55	4.8	208	VR56	150	—	0.3		
		To gate CB voice circuits, short Q527 (on VG-11) across C-E momentarily.									
CB	H	INTERNAL	Q529 col- lector	VR67	1.25	800	Shift scope V IN to pin 34 on VG-11	—	60	—	0.2
CB	L		Q530 col- lector	VR68	1.8	555					
			Slide ADD VOICE knobs upward,(Tb, GU, MB, respectively). Push in CYMBAL-HIGH HAT (CANCEL VOICE) when adjusting MB.								
Tb		reset TRIG. to INTERNAL	Pin 34	—	—	—		—	220	VR62	0.25
GU	H		on	VR59	8.0	125		—	—	VR63	0.3
	L		VG-11	VR59	13.0	77					
MB	H		IC501 pin 8	VR64	0.162	6170	Shift scope V IN to pin 34 on VG-11	—	50	—	0.35
	M		IC501 pin 4	VR65	0.178	5620					
	L		IC501 pin 10	VR66	0.245	4080					



PARTS LIST

		ICs
		179-022 μ PD8048C-015 computer
081-113	Cabinet no.117	There are some versions of 8048. Each has an exclusive resident program. Specify 8048C-015 for the CR-78 replacement.
111-020	Base no.20 (foot)	
072-235	Panel no.235	
076-356	Name plate no.356 rear OUTPUT-COMBI.	
076-367	Name plate no.367 rear EXT. CLOCK-WRITE	179-023 AM2708P-023 ROM
061-218	Chassis no.218 front	020-181 μ PD5101C-E RAM
061-219	Chassis no.219 main	020-141 *74LS175N (TTL)
061-220	Chassis no.220 rear	020-196 *14175B or 74C175 (MOS) *refer to GL-9A parts layout
061-234	Chassis no.234 sub	020-064 μ PC4558
061-235	Chassis no.235 sub	020-180 74LS174N
061-236	Chassis no.236 sub	020-138 74LS138N
KNOBS. BUTTONS		020-124 74LS04N
016-043	Knob no.43 TEMPO	020-120 74LS00N
016-044	no.44 FILL. MEASURE. INSTRUMENT. ACCENT	020-084 MC14069BCP
016-080	No.80 CLEAR. CANCEL	020-041 MC14013BCP
016-081	No.81 power switch	020-169 MC14001BCP
016-048	No.48 slider	020-160 BA-662B VCA
016-067	No.67 MEMORY-ALL	020-073 μ A78M15 regulator +15V
016-008	Button No.8 gray	020-197 μ A78M05 or μ A7805 +5V
016-085	No.85 white	020-198 μ A78L05 -5V
016-086	No.86 red	DIODES
016-087	No.87 green	
016-088	No.88 yellow	018-059 1S1588
016-089	No.89 blue	018-082 W-02 bridge 1.5A
COILS. TRANSFORMERS		019-013 SLP-131B LED red
		SWITCHES
022-030	Coil no.30 45mH	
022-031	no.31 1R	001-215 Power SDG-5P 100V
022-033	no.33 3R 700mH	001-216 SDG-5P 117V
022-124N	PT no.124N 100V	001-217 SDG-5P 220/240V
022-124C	PT no.124C 117V	001-273 KCA10037 keyboard
022-124D	PT no.124D 220/240V	001-206 HSW-0372-01-030 slide 8,16,COMBI
TRANSISTORS		001-243 SRM1025 rotary MEASURE
017-105	2SA1015-Y	001-242 SRM101C rotary FILL IN
017-106	2SC1815-GR	001-239 SUFA2 push gang ROCK-DISCO 2
017-021	2SC900-F	001-240 SUFB2 push gang WALTZ-
017-046	2SC828-R (NZ) for noise	001-231 SLR322 lever Rhythm A/B. AUTO/MANU.
		001-245 SLR323 lever FADE IN/OUT
		001-246 SLR823 lever MEMO/PLAY/ALL
		001-241 SUF53 1push gang CLEAR. CANCEL VOICE
		001-244 SRA202B rotary INSTRUMENT

CR-78

		PCBs
143-011A	VG-11A(etch mask 052-437A)	For the replacement, use PCBs listed above, interchangeable improved versions.
142-009B	GL-9B (052-438B)	
148-014	RS-14 (WALTZ-)(052-445)	
148-015A	RS-15A (VARI.MEASURE) (052-444A)	
148-017	RS-17 (PROGRAM. ROCK-) (052-446)	POTENTIOMETERS
149-100A	OP-100A (052-449A)	
149-103A	OP-103A (052-447A)	
149-104A	OP-104A (052-464) (use 104A as a replacement for OP-129)	
026-024	EVHCOAP25B15 100KB TEMPO	Trimmers
026-021	EVHCOAP24B14 10KB ACCENT	
029-410	LYE6B001-10KB VOL. ADD VOICE	
029-411	LYE6B001-50KB BALANCE	
028-001	EVTR4A00 (SR19) 500	CAPACITORS
028-003	EVTR4A00 (SR19) 5K	
028-004	EVTR4A00 (SR19) 10K	
028-005	EVTR4A00 (SR19) 20K	
028-006	EVTR4A00 (SR19) 50K	FUSES. FUSE CLIP
028-007	EVTR4A00 (SR19)100K	
032-095	0.47mfd 35V K tant.	
035-109	ECQM6103KZ 600V polyester	
008-024	SGA 0.5A prim. sec +5V 100/117V	Clip TF-758
008-026	SGA 1A sec +15V 100/117V	
008-022	SGA 0.125A sec -5V 100.117V	
008-053	CEE T50mA sec -5V 220/240V	
008-060	CEE T250mA sec +15V 220/240V	MISCELLANEOUS
008-062	CEE T400mA sec +5V 220/240V	
008-060	CEE T250mA prim/sec +15V 220/240V	
012-003	Clip TF-758	

JUNE 20, 1979

		MISCELLANEOUS
009-012	Jack SG7622	IC Sockets
012-040	ICC30-040-350G 40-pin	
012-041	ICC30-024-350G 24-pin	
012-042	ICC30-022-350G 22-pin	
047-003	Line cord strain relief BU4801	Cord clamp 1702B
047-023	Cord clamp 1702B	
120-001	Long nut (spacer/stand off) no.1 3x10mm	
		PARTS ORDERING INFORMATION
		When ordering parts, be sure to include the following information:
		1. Model and Serial Number
		2. Part Number
		3. Part Name
		If the necessity for a non-listed part arises, please write describing the parts location and function as well as model and serial number of the unit.

MANUAL CHANGE INFORMATION

ADJUSTMENT page 15

1-2. T = 10ms ----- 200ms
2-1. 4 to 55 ----- 4 to 5

GL-9 with N-SB3

1. N-SB3 being lower in voltage, can be sufficiently charged regardless of D109 existence which protects IC102 and IC103 against high voltage during an absence of N-SB3.

(after D109 removed)

- HIGHER voltage will
ruin IC102 and IC103.

2. Contrary to D109, D221 and R237 are harmful to N-SB3, remove them before installing N-SB3.

IC pins and patterns
misregistered

